

TJ axle bracket kit location drawing

Standard setup 5.5° of lift SYE kit the pinion angle will be approx. 23 degrees.
 If you are using a high pinion axle the pinion angle will be approx. 5 degrees less.
 This means the truss should be welded on at approx. 11 degrees.
 Remember these are approx. angle make sure you double check angles
 for your setup.

