

Clayton Off Road
COR-4109010
Jeep Wrangler Front Axle Disconnect Skid Plate (2018+, JL)

Note: Part Number COR-5209011 Jeep Wrangler Steering Stabilizer Relocation Bracket Kit (2018 & Up, JL) is required with this skid plate if you want to run a steering stabilizer.



NOTES: This product may require general welding, fabrication and automotive mechanic skills. Welding should only be done by a competent welder. Clayton Off Road implies no guarantees or warranties and is not liable for improper installation. Some grinding and fitment may be required when installing this product. Every vehicle varies slightly and some fabrication may be required.

For more information please visit our website.

Refer to pictures below.

Step 1: Install part number COR-5209011 Jeep Wrangler Steering Stabilizer Relocation Bracket Kit (2018 & Up, JL).

Step 2: Remove old front axle disconnect skid plate.

Step 3: Slide new front axle disconnect skid plate into position on axle.

Step 4: Install two supplied flat head screws in the bottom of the skid plate.

Step 5: Install two upper rear factory bolts on the skid plate.

Step 6: Install two upper front factory bolts in the skid plate.

Step 7: Tighten two flat head screws first.

Step 8: Tighten remaining four factory bolts.

Step 9: Use supplied wire tie to secure wire to disconnect motor.



