



Mojave Shock Bushing Kit

Installation Guide

www.falconshocks.com



UPPER

LOWER

TOOLS NEEDED:

- Bench Vise
- 1-5/16 in or 34mm Deep Socket
- 11/16in or 17mm Socket
- Grease

UPPER BUSHINGS



- Place 1-5/16in socket over short side of shock bushing. (Socket sits flush to shock as shown)
- Slowly press with vise. Bushing will exit into the socket.

- Apply plenty of grease to bushing and shock eyelet.
- Verify long end of bushing is facing vehicle side of shock as shown.
- Slowly press in with vise. **Verify bushing is pressing in straight and readjust if needed.**

LOWER BUSHINGS



- Use 1-5/16 socket to cover one side of bushing. (Socket sits flush to shock)
- 11/16 socket should orient with square driver end flush with hard inner part of bushing.
- Slowly press with vise. Bushing will exit into the larger socket.

- Use plenty of grease on bushing and shock eyelet.
- Place large socket onto side of shock eyelet and lower bushing on opposite side.
- Slowly press with vise. **Verify bushing is pressing in straight and readjust if needed.**