

**Clayton Off Road
COR-4500200
Jeep Adjustable Front Track Bar (1984-2006, TJ/LJ/XJ/ZJ)**



NOTES: This product may require general welding, fabrication and automotive mechanic skills. Welding should only be done by a competent welder. Clayton Off Road implies no guarantees or warranties and is not liable for improper installation. Some grinding and fitment may be required when installing this product. Every vehicle varies slightly and some fabrication may be required. For more information please visit our website.

Refer to pictures below.

Step 1: Remove old track bar.

Step 2: Install one of the following track bar brackets, COR-4500400, COR-4500410, COR-4500420.

Step 3: Drill track bar bracket on axle to $9/16$ " diameter.

Step 4: Center frame on axle.

Step 5: Measure length from axle side mount to frame side mount.

Step 6: Adjust track bar to length and run jam nut up to track bar tube.



Step 7: Install new track bar with adjustment end on frame.

Step 8: Install track bar bolts and nuts.

Step 9: Torques both bolts to 110 ft-lb.

Step 10: Tighten jam nut using a $1-7/16$ " wrench.

Step 11: Make sure Johnny Joint at frame side is centered in bracket.



Refer to drawing below for minimum and maximum lengths.

